

Installation Steps

Step 1:

Fix the bracket on the lamp with screws

Step 2:

Adjust the bracket angle based on your latitude and longitude. 15–30 degree is suggested.


Step 3:

Switch on the lamp with the button.

Press down means off, while press up means on.

Step 4:

Fix the bracket on the pole with screws



Please read this manual before installation

Unpacking inspection

- 1. Open the packing and check the product carefully, please handle with care.
- If the product has any damage, please keep the packaging, and contact with our company in time.

Note

- 1. The work environment: -20°C+60°C
- When you install the product, please use the solar panel as much as possible in the direction of the sun that can get the maximize energy. At the same time please avoid the barrier shadow such as building and trees, otherwise it will reduce the efficiency of solar panel, result in the product working time will be shortened.
- 3. The surface cleanliness of solar panel also will affect the generating efficiency of solar panel. So, on the surface like dust, leaves and oil, it needs to be cleaned regularly.
- 4. Please install the product according to the correct installation procedure, and the product must be installed and maintained by the qualified professional experts.